

SECTION 7

COACH HOUSE ROOF (shown in pink)

Strip off all welsh slate and replace with like for like materials to southeast elevation.

Strip off all ~~welsh~~ Westmorland slates and replace with like for like materials to the northwest elevation.

Replace all defective timbers found in roof with like for like new material.

Cover roof with breather felt and treated battens.

Replace all lead hips and ridge and box gutters with like for like.

Remove top of old and defective roof vent (see photograph) and roof over with slate to north end of northwest facing roof.

Provide and fix new gutter to northwest facing roof using like for like materials.

BARN & STABLE ROOF (shown in green)

Strip off all welsh slate and replace with like for like materials to both southwest and northeast elevation.

Cover both roof slopes with breather felt and treated battens

Replace all defective timbers found in roof with like for like new materials

Provide and fix new gutter to southwest facing roof using like for like materials

Replace all lead to ridge and hips.