



WHERE NEW SVP'S ENTER GROUND FLOOR THEY ARE TO BE TAKEN ACROSS U/S OF 1F IN CAST IRON TO CONNECT TO EXISTING FOUL WATER DRAINAGE SYSTEM.

LOCATIONS OF EXISTING FOUL WATER DRAINS TO BE REPORTED TO ARCHITECTS AS SOON AS POSSIBLE TO ALLOW FOR REDESIGN AS REQUIRED.

AREA NOT SURVEYED